



MODEL : 1AC/JA30



*B : APPLY LOCTITE 242

PARTS LIST (1AC/JA30)***WHEN ORDERING SPARE PARTS,PLEASE STATE ITEM No ,PART NO.AND DESCRIPTION.**

ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
01	HS05080BW-16	HEX. SOC. HD. BOLT+SW	4	49	SS04070B-12	SET SCREW	1				
03	11100302	CAP	1	50	11505001	MAGAZINE	1				
04	12100401	SEAL**	1	51	HS04070BW-08	HEX. SOC. HD. BOLT+SW	4				
05	12100501	SPRING**	1	52	11005201	TAIL COVER	1				
06	OR13824N	O RING**	1	53	11505301	PUSHER	1				
07	11100702	GASKET**	1	54	12105401	SPRING**	1				
08A	12100801A	HEAD VALVE ASM.	1	55	12105501	NAIL GUIDE LINER	1				
11	OR31824N	O RING**	1	57	HS05080B-07	HEX. SOC. HD. BOLT	1				
13	OR17730N	O RING**	1	61A	12106101A	BRACKET ASSEMBLY	1				
14A-1	11501407A	DRIVER ASSEMBLY**	1	64	HS05080B-16	HEX. SOC. HD. BOLT	1				
14A-2	11501406A	DRIVER ASSEMBLY**	1	65	LN0500N	LOCK NUT	1				
18	OR44431N	O RING**	1	66	11106601	COVER	1				
19	11401901	CYLINDER	1	67	12106401	AIR PLUG	1				
19-3	11101903	COLLAR	1	68	OR40030N	O RING**	1				
20	11502001	BUMPER**	1	71	US05080B-06	UM. HD. BOLT	1				
21	OR28318N	O RING**	1	72	FW050120B-10	FLAT WASHER	1				
23	11102307	BODY	1	73	12103301	SEAL	1				
24	OR01919N	O RING**	2	74	13907403	EXHAUST COVER	1				
25	12102501	JOINT GUIDE	1	76	RP3020S	ROLLED PIN	1				
26	11002601	SPRING	1								
27	11002704	GUIDE SAFETY LEVER	1								
31	11003101	SAFETY LEVER	1								
32	11103201	STEPPED PIN	2								
33	11006903A	TRIGGER VALVE ASSEMBLY^	1								
40A	15104501A	TRIGGER ASSEMBLY	1								
41A	27204101A	LATCH	1								
42	US05080B-25	UM. HD. BOLT	2								
43	SW0500W	SPRING WASHER	2								
44	11504401	DRIVER GUIDE COVER	1								
44A	11504402A	DRIVER GUIDE COVER ASM	1								
45	12104501	SET PLATE	1								
46	HS04070B-12	HEX. SOC. HD. BOLT	2								
47	11504702	DRIVER GUIDE	1								
48	11504801	MAGAZINE COVER	1								